



TO INSTALL THE BIB TAP:

Make a seal by wrapping P.T.F.E. tape around the male thread several times opposite to the thread direction. Screw the tap into the inlet leg as far as it will go without going past the vertical spout alignment point.

NOTE:

The tape may need to be built up more than once to ensure the seal is correct, and the tap cannot be easily unscrewed. Always water test the seal after installment.